

# How to use Glass & Multi- Surface Cleaner

# 6



**NCL**<sup>®</sup>  
National Chemical  
Laboratories

World Class  
Cleaning Solutions<sup>®</sup>

Philadelphia, PA 19123  
1-800-NAT-CHEM • (215) 922-1200  
E-mail: [info@nclonline.com](mailto:info@nclonline.com)  
Web Site: [www.nclonline.com](http://www.nclonline.com)

## DISPENSING DIRECTIONS:

Attach READY-SET-CLEAN<sup>®</sup> (RSC) Dispensing Unit to the bottle by threading the unit onto the bottle and tighten securely. Attach water hose to the gun and dispense product by squeezing the flow control handle. Use the locking switch if desired for "hands free" filling of buckets and automatic scrubbers.

**NOTE:** The READY-SET-CLEAN<sup>®</sup> Dispensing Unit is designed for use with any and all RSC products. Dilution tips built into the product containers provide precise, accurate dilution for every product, every time.

## DIRECTIONS FOR USE:

### FOR SPRAY & WIPE CLEANING

**APPLICATIONS:** Fill a properly labeled quart container with GLASS AND HARD SURFACE CLEANER solution from the READY-SET-CLEAN<sup>®</sup> Dispensing Unit at a dilution rate of 1:64 (2 oz per gallon) and tighten trigger sprayer. Use cold tap water only. Apply cleaner solution onto a clean microfiber cleaning cloth. Using the moistened microfiber cloth, apply cleaner to surfaces and scrub as needed. Then wipe dry with a clean microfiber cleaning cloth.

**NOTE:** Improper use or dilution may cause damage to surfaces and may increase the risk of health effects.



**DISPOSE OF UNUSED PRODUCT IN ACCORDANCE WITH LOCAL, STATE AND FEDERAL REGULATIONS - PLEASE RECYCLE CONTAINER**

PPE INFORMATION: Respiratory protection is generally not required. No special ventilation is normally required. The use of safety glasses is recommended. No other protective equipment is required.

**A PPE**

